	Usable volume	1%	2%	5%	10%
T 310 (H)	0,7	7 ml	14 ml	35 ml	70 ml
T 420	1,2 l	12 ml	24 ml	60 ml	120 ml
T 460 (H)	1,9 l	19 ml	38 ml	95 ml	190 ml
T 470 H	·				
T 490 DH					
TS 540	4,8 l	48 ml	96 ml	240 ml	480 ml
T 570 (H)	2,2	22 ml	44 ml	110 ml	220 ml
T 660 H	4,3 l	43 ml	86 ml	215 ml	430 ml
TP 690	4,0 l	40 ml	80 ml	200 ml	400 ml
TP 680 DH					
T 700 (H)	7,5 l	75 ml	150 ml	375 ml	750 ml
T 710 DH					
T 780 (H)	9,0	90 ml	180 ml	450 ml	900 ml
T 760 DH					
T 820 H	12,9 l	129 ml	258 ml	645 ml	1,29 l
T 840 DH					
T 890 (H)	20,6 l	206 ml	412 ml	1,0 l	2,0 l
T910 DH					
Elmasonic X-tra 50 H	3,43 l	34 ml	68 ml	171,5 ml	343 ml
Elmasonic X-tra 70 H	4,70 l	47 ml	94 ml	235 ml	470 ml
Elmasonic X-tra 150 H	10,5 l	105 ml	210 ml	525 ml	1,05 l
TI-H 5	3,5 l	35 ml	70 ml	175 ml	350 ml
TI-H 10	8,6 l	86 ml	172 ml	430 ml	860 ml
TI-H 15	12,2 l	122 ml	244 ml	610 ml	1,22 l
TI-H 20	16,8 l	168 ml	336 ml	840 ml	1,68 l
TI-H 25	19,8 l	198 ml	396 ml	990 ml	1,98 l
TI-H 55	45,0 l	450 ml	900 ml	2,25	4,5 l
TI-H 80	67,5 l	675 ml	1,35 l	3,38	6,75 l
TI-H 115	90 l	900 ml	1,8	4,5	9,0 l
TI-H 160	135 l	1,35 l	2,7 l	6,75 l	13,5 l

Fill the tank up to the marked level with water (city or distilled water). Then add the correct quantity of the cleaner. For bigger-sized cleaning items please take the displacement volume into consideration. Operate the ultrasonics for approx. 5 minutes before cleaning.